

DART SERVICE INSTRUCTION

**TO AMEND INSTALLATION INSTRUCTIONS IIN-D119-646 REV. D
AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D119-646 REV. 3**
REF FAA STC: SR02024SE
REF EASA STC: 10040294

1.0 PURPOSE:

The purpose of this Dart Service Instructions is to add D119-646-313/-314 Skidtube Protector Kit to make the D119-646-011/-012/-041/-111/-112/-141/-211/-212/-241 Skidtube Kits and the D119-646-013/-014/-043/-113/-114/-143/-213/-214/-243 Float Skidtube Kits compatible with the 109-0812-68-105 Hoist Structural Provision Kit and the 109-0816-18-301 Rappelling Kit. The D119-646-313 Skidtube Protector, LH replaces the 109-B710-05-201 kit and the D119-646-314 Skidtube Protector, RH replaces the 109-B710-05-202 kit.

2.0 D119-646-011/-012/-041/-111/-112/-141 STANDARD SKIDTUBE MODIFICATION:

The following instructions are for modifying the D119-646-011/-012/-041/-111/-112/-141 Skidtube at CHG 004 and prior, to allow for D119-646-313/-314 Skidtube Protector Kit installation:

- 2.1 Remove D3492-045 Plug Assemblies from two locations on each side of the skidtube as shown in Figure 3.
- 2.2 Position D5376-1 drilling jig tool with the arrow pointing fwd as shown in Figure 3. Use 2x AN3-45A bolts to hold the jig in place. Transfer drill 4x $\varnothing 0.129$ " (#30 drill) holes from D5376-1 drilling jig to skidtube ridge as shown in Figure 3. **Caution:** Drill perpendicular to the skidtube ridge.
- 2.3 Remove drilling jig. Using a 5/16" drill, open up the pilot holes and drill through the skidtube ridge and center web inside of the skidtube. **Caution:** Drill perpendicular to the skidtube ridge.
- 2.4 Countersink 4x 5/16" holes to $\varnothing 0.348$ " (8.84mm) x 100° as shown in Figure 3 and deburr.
- 2.5 Repeat steps 2.2 to 2.4 for the opposite side of the skidtube.
- 2.6 Vacuum the debris from inside of the skidtube. Touch up affected area using (Alodine 1200 or 1201) per MIL-DTL-5541.
- 2.7 Install 8x D5374-3 Bushings in the new holes. Seal bushings with Sikaflex-241/-291 or Proseal 890 or MIL-S-8802 Class 'B2' sealant as shown in Section C-C.

D119-646-011/-012/-041/-111/-112/-141 Skidtube at CHG 005 and subsequent, do not require modification. Discard D5376-1 Drilling jig and D5374-3 Bushings.

D	REVISED DSI TO INCLUDE SKIDTUBE MODIFICATION INSTRUCTIONS FOR FLOAT SKIDTUBES D119-013/-014/-043/-113/-114/-143/-243 CHG 008 AND SUBSEQUENT AND D119-646-213/-214 CHG 007 AND SUBSEQUENT, REF NCR17-6586	MW	18.08.24
C	REVISED DSI TO INCLUDE INSTALLATION INSTRUCTIONS FOR FLOAT SKIDTUBES D119-646-013/-014/-043/-113/-114/-143/-213/-214/-243, REF CIR 17-101	VS	17.06.27
B	REVISED DSI TO INCLUDE INSTALLATION INSTRUCTIONS FOR SKIDTUBE ASSY D119-646-011/-012/-111/-112/-041/-141/-241 CHG 005 & SUBSEQUENT AND SKIDTUBE ASSY D119-646-211/-212 CHG 006 & SUBSEQUENT. ADDED NAS1149D0316J WASHERS TO BOM.	WK	17.02.16
A	NEW ISSUE	RF	15.12.10
REV.	DESCRIPTION	BY	DATE
DESIGN	RF	DART AEROSPACE USA, INC. EUGENE, OR	
DRAWN	MW		
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 1 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS- 11	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	<small>COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.</small>	

APPROVED

3.0 D119-646-211/-212/-241 STANDARD SKIDTUBE MODIFICATION:

The following instructions are for modifying the D119-646-211/212 Skidtube at CHG 005 and prior, and D119-646-241 at CHG 004 and prior, to allow for D119-646-313/-314 Skidtube Protector Kit installation:

- 3.1 Temporarily remove D3849-043 Training Wearplate from aft end of the skidtube per ICA-D119-646 Section 32.
- 3.2 Position D5376-1 drilling jig tool with the arrow pointing fwd as shown in Figure 3. Use 2x AN3-45A bolts to hold the jig in place. Transfer drill 4x $\varnothing 0.129$ " (#30 drill) holes from D5376-1 drilling jig to skidtube ridge as shown in Figure 3. **Caution:** Drill perpendicular to the skidtube ridge.
- 3.3 Remove drilling jig. Using a 5/16" drill, open up the pilot holes and drill through the skidtube ridge and center web inside of the skidtube. **Caution:** Drill perpendicular to the skidtube ridge.
- 3.4 Countersink 4x 5/16" holes to $\varnothing 0.348$ " (8.84mm) x 100° as shown in Figure 3 and deburr.
- 3.5 Repeat steps 3.2 to 3.4 for the opposite side of the skidtube.
- 3.6 Vacuum the debris from inside of the skidtube. Touch up affected area using (Alodine 1200 or 1201) per MIL-DTL-5541.
- 3.7 Install 8x D5374-3 Bushings in the new holes. Seal bushings with Sikaflex-241/-291 or Proseal 890 or MIL-S-8802 Class 'B2' sealant as shown in Section C-C.

D119-646-211/-212 Skidtube at CHG 006 and subsequent and D119-646-241 Skidtube at CHG 005 and subsequent, do not require modification. Discard D5376-1 Drilling jig and D5374-3 Bushings.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC.	
DRAWN	MW	EUGENE, OR	
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 2 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC.	
<small>THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.</small>			

4.0 D119-646-013/-014/-043/-113/-114/-143 FLOAT SKIDTUBE MODIFICATION:

D The following instructions are for modifying the D119-646-013/-014/-043/-113/-114/-143 Float Skidtube at CHG 005 and prior, to allow for D119-646-313/-314 Skidtube Protector Kit Installation:

- 4.1 Remove D3492-045 Plug Assemblies from two locations on each side of the skidtube as shown in Figure 3.
- 4.2 Position D5376-1 drilling jig tool with the arrow pointing fwd as shown in Figure 3. Use 2x AN3-45A bolts to hold the jig in place. Transfer drill 4x $\varnothing 0.129$ " (#30 drill) holes from D5376-1 drilling jig to skidtube ridge as shown in Figure 3. **Caution:** Drill perpendicular to the skidtube ridge.
- 4.3 Remove drilling jig. Using a 5/16" drill, open up the pilot holes and drill through the skidtube ridge and center web inside of the skidtube. **Caution:** Drill perpendicular to the skidtube ridge.
- 4.4 Countersink 4x 5/16" holes to $\varnothing 0.348$ " (8.84mm) x 100° as shown in Figure 3 and deburr.
- 4.5 Repeat steps 4.2 to 4.4 for the opposite side of the skidtube.
- 4.6 Vacuum the debris from inside of the skidtube. Touch up affected area using (Alodine 1200 or 1201) per MIL-DTL-5541.
- 4.7 Install 8x D5374-3 Bushings in the new holes. Seal bushings with Sikaflex-241/-291 or Proseal 890 or MIL-S-8802 Class 'B2' sealant as shown in Section C-C.

D D119-646-013/-014/-043/-113/-114/-143 Skidtube at CHG 006 and subsequent, do not require modification. Discard D5376-1 Drilling jig and D5374-3 Bushings.

5.0 D119-646-213/-214/-243 FLOAT SKIDTUBE MODIFICATION:

D The following instructions are for modifying the D119-646-213/-214 Float Skidtube at CHG 006 and prior, and D119-646-243 Float Skidtube at CHG 005 and prior (with the exception of Float Skidtubes S/N S089679, S094961, S106182, S106198 which do not need to be modified), to allow for D119-646-313/-314 Skidtube Protector Kit installation:

- 5.1 Temporarily remove D3849-045 Training Wearplate from aft end of the skidtube per ICA-D119-646 Section 32.
- 5.2 Position D5376-1 drilling jig tool with the arrow pointing fwd as shown in Figure 3. Use 2x AN3-45A bolts to hold the jig in place. Transfer drill 4x $\varnothing 0.129$ " (#30 drill) holes from D5376-1 drilling jig to skidtube ridge as shown in Figure 3. **Caution:** Drill perpendicular to the skidtube ridge.
- 5.3 Remove drilling jig. Using a 5/16" drill, open up the pilot holes and drill through the skidtube ridge and center web inside of the skidtube. **Caution:** Drill perpendicular to the skidtube ridge.
- 5.4 Countersink 4x 5/16" holes to $\varnothing 0.348$ " (8.84mm) x 100° as shown in Figure 3 and deburr.
- 5.5 Repeat steps 5.2 to 5.4 for the opposite side of the skidtube.
- 5.6 Vacuum the debris from inside of the skidtube. Touch up affected area using (Alodine 1200 or 1201) per MIL-DTL-5541.
- 5.7 Install 8x D5374-3 Bushings in the new holes. Seal bushings with Sikaflex-241/-291 or Proseal 890 or MIL-S-8802 Class 'B2' sealant as shown in Section C-C.

D D119-646-213/-214 Float Skidtube at CHG 007 and subsequent, D119-646-243 Float Skidtube at CHG 006 and subsequent and D119-646-243 Float Skidtubes S/N S089679, S094961, S106182, S106198, do not require modification. Discard D5376-1 Drilling jig and D5374-3 Bushings.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC.	
DRAWN	MW	EUGENE, OR	
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 3 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	

6.0 INSTALLATION OF D119-646-313/-314 ONTO D119-646-011/-012/-041/-111/-112/-141:

- 6.1 Remove all D3492-045 Plug Assemblies from skidtube fwd of the ground handling wheel lugs.
- 6.2 For installation of the D119-646-313/-314 Skidtube Protector Kit onto the D119-646-011/-012/-041/-111/-112/-141 Skidtube at CHG 005 and subsequent, Install NAS1149D0316J and NAS1149D0332J washers as shown in Detail G, Figure 6.
- 6.3 If the D119-646-314 Skidtube Protector Kit is required for hoisting operations on the RH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 6.4 If the D119-646-313 Skidtube Protector Kit is required for hoisting operations on the LH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 6.5 If the D119-646-314 Skidtube Protector Kit is required for rappelling operations on the RH side of the aircraft install D5371-2 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 6.6 If the D119-646-313 Skidtube Protector Kit is required for rappelling operations on the LH side of the aircraft install D5371-1 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 6.7 Install D5369-2 Cable Guard on the RH side of the aircraft using 6x AN3-47A bolts, 6x D5374-1 Bushings, 6x D4506-3 Washers, 12x NAS1149D0332J washers, 6x MS21042L3 nuts as shown in Figure 1 Section A-A. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 6.8 Install D5369-1 Cable Guard on the LH side of the aircraft using 6x AN3-47A bolts, 6x D5374-1 Bushings, 6x D4506-3 Washers, 12x NAS1149D0332J washers, 6x MS21042L3 nuts as shown in Figure 1 Section A-A. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 6.9 Update aircraft log book to indicate installation of the D119-646-313/-314 kit and adjust weight and balance record for the aircraft with weight and balance data provided in Section 11.0 of this document.

NOTE: Additional NAS1149D0332J washers may be installed under the nuts to ensure 1.5 - 4 threads in safety on the bolts. Although not generally necessary, it is also acceptable to replace the AN3 bolts provided with longer or shorter AN3 bolts, if required.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC.	
DRAWN	MW	EUGENE, OR	
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 4 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. <small>THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.</small>	

7.0 INSTALLATION OF D119-646-313/-314 ONTO D119-646-211/-212/-241:

- 7.1 Remove and discard all hardware attaching the training wearplates in front of the skidtube ground handling lugs.
- 7.2 For installation of the D119-646-313/-314 Skidtube Protector Kit onto the D119-646-211/-212 Skidtube at CHG 006 and subsequent, and D119-646-241 Skidtube at CHG 005 and subsequent, remove all D3492-045 Plug Assemblies from skidtube fwd of the ground handling wheel lugs & install NAS1149D0316J and NAS1149D0332J washers as shown in Detail G, Figure 6.
- 7.3 If the D119-646-314 Skidtube Protector Kit is required for hoisting operations on the RH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 7.4 If the D119-646-313 Skidtube Protector Kit is required for hoisting operations on the LH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 7.5 If the D119-646-314 Skidtube Protector Kit is required for rappelling operations on the RH side of the aircraft install D5371-2 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 7.6 If the D119-646-313 Skidtube Protector Kit is required for rappelling operation on the LH side of the aircraft install D5371-1 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 7.7 Reinstall the D3849-043 Training Wearplate on the aft end of the skidtube per ICA-D119-646 Section 32, except for hardware under D5369-1/-2 Cable Guard.
- 7.8 Install D5369-2 Cable Guard on the RH side of the aircraft using 6x AN3-50A bolts, 6x D5374-1 Bushings, 6x D3904-1 Washers, 6x MS21042L3 nuts as shown in Figure 2 Section B-B. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 7.9 Install D5369-1 Cable Guard on the LH side of the aircraft using 6x AN3-50A bolts, 6x D5374-1 Bushings, 6x D3904-1 Washers, 6x MS21042L3 nuts as shown in Figure 2 Section B-B. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 7.10 Update aircraft log book to indicate installation of the D119-646-313/-314 kit and adjust weight and balance record for the aircraft with weight and balance data provided in Section 11.0 of this document.

NOTE: Additional NAS1149D0332J washers may be installed under the nuts to ensure 1.5 - 4 threads in safety on the bolts. Although not generally necessary, it is also acceptable to replace the AN3 bolts provided with longer or shorter AN3 bolts, if required.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC.	
DRAWN	MW	EUGENE, OR	
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 5 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. <small>THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.</small>	

8.0 INSTALLATION OF D119-646-313/-314 ONTO D119-646-013/-014/-043/-113/-114/-143:

- 8.1 Remove all D3492-045 Plug Assemblies from skidtube fwd of the ground handling wheel lugs.
- 8.2 Trim the D5369-1/-2 Cable Guard per Figure 7.
- 8.3 For installation of the D119-646-313/-314 Skidtube Protector Kit onto the D119-646-013/-014/-043/-113/-114/-143 Float Skidtube, install NAS1149D0316J and NAS1149D0332J washers as shown in Detail G, Figure 6.
- 8.4 If the D119-646-314 Skidtube Protector Kit is required for hoisting operations on the RH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 8.5 If the D119-646-313 Skidtube Protector Kit is required for hoisting operations on the LH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 8.6 If the D119-646-314 Skidtube Protector Kit is required for rappelling operations on the RH side of the aircraft install D5371-2 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 8.7 If the D119-646-313 Skidtube Protector Kit is required for rappelling operations on the LH side of the aircraft install D5371-1 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 8.8 Install D5369-2 Cable Guard on the RH side of the aircraft using 2x AN3-47A bolts, 2x D5374-1 Bushings, 2x D4506-3 Washers, 4x NAS1149D0332J washers, 2x MS21042L3 nuts as shown in Figure 7 Section A-A. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 8.9 Install D5369-1 Cable Guard on the LH side of the aircraft using 2x AN3-47A bolts, 2x D5374-1 Bushings, 2x D4506-3 Washers, 4x NAS1149D0332J washers, 2x MS21042L3 nuts as shown in Figure 7, Section A-A. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 8.10 Update aircraft log book to indicate installation of the D119-646-313/-314 kit and adjust weight and balance record for the aircraft with weight and balance data provided in Section 11.0 of this document.

NOTE: Additional NAS1149D0332J washers may be installed under the nuts to ensure 1.5 - 4 threads in safety on the bolts. Although not generally necessary, it is also acceptable to replace the AN3 bolts provided with longer or shorter AN3 bolts, if required.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC.	
DRAWN	MW	EUGENE, OR	
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 6 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	

9.0 INSTALLATION OF D119-646-313/-314 ONTO D119-646-213/-214/-243:

- 9.1 Remove and discard all hardware attaching the training wearplates in front of the skidtube ground handling lugs.
- 9.2 Trim the D5369-1/-2 Cable Guard per Figure 8.
- 9.3 For installation of the D119-646-313/-314 Skidtube Protector Kit onto the D119-646-213/-214/243 Float Skidtube, remove all D3492-045 Plug Assemblies from skidtube fwd of the ground handling wheel lugs & install NAS1149D0316J and NAS1149D0332J washers as shown in Detail G, Figure 6.
- 9.4 If the D119-646-314 Skidtube Protector Kit is required for hoisting operations on the RH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 9.5 If the D119-646-313 Skidtube Protector Kit is required for hoisting operations on the LH side of the aircraft install D5372-1 Plug using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 4 Detail E. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 9.6 If the D119-646-314 Skidtube Protector Kit is required for rappelling operations on the RH side of the aircraft install D5371-2 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 9.7 If the D119-646-313 Skidtube Protector Kit is required for rappelling operation on the LH side of the aircraft install D5371-1 Hook using 4x AN3-45A bolts, 8x NAS1149D0332J washer and 4x MS21042L3 nuts as shown in Section C-C and Figure 5 Detail F. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 9.8 Reinstall the D3849-045 Training Wearplate on the aft end of the skidtube per ICA-D119-646 Section 32, except for hardware under D5369-1/-2 Cable Guard.
- 9.9 Install D5369-2 Cable Guard on the RH side of the aircraft using 2x AN3-50A bolts, 2x D5374-1 Bushings, 2x D3904-1 Washers, 2x MS21042L3 nuts as shown in Figure 8 Section B-B. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 9.10 Install D5369-1 Cable Guard on the LH side of the aircraft using 2x AN3-50A bolts, 2x D5374-1 Bushings, 2x D3904-1 Washers, 2x MS21042L3 nuts as shown in Figure 8 Section B-B. Torque bolts to 15-25 in-lbs (1.7-2.8 N-m).
- 9.11 Update aircraft log book to indicate installation of the D119-646-313/-314 kit and adjust weight and balance record for the aircraft with weight and balance data provided in Section 11.0 of this document.

NOTE: Additional NAS1149D0332J washers may be installed under the nuts to ensure 1.5 - 4 threads in safety on the bolts. Although not generally necessary, it is also acceptable to replace the AN3 bolts provided with longer or shorter AN3 bolts, if required.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC.	
DRAWN	MW	EUGENE, OR	
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 7 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. <small>THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.</small>	

10.0 PARTS LIST:

Qty. -313	Qty. -314	PART NUMBER	DESCRIPTION
X		D119-646-313	SKIDTUBE PROTECTOR, LH
	X	D119-646-314	SKIDTUBE PROTECTOR, RH
6	6	D3904-1	WASHER
6	6	D4506-3	WASHER
1		D5369-1	CABLE GUARD, LH
	1	D5369-2	CABLE GUARD, RH
1		D5371-1	HOOK, LH
	1	D5371-2	HOOK, RH
1	1	D5372-1	PLUG
6	6	D5374-1	BUSHING
8	8	D5374-3	BUSHING
1	1	D5376-1	DRILLING JIG
4	4	AN3-45A	BOLT
6	6	AN3-47A	BOLT
6	6	AN3-50A	BOLT
18	18	NAS1149D0332J	WASHER
4	4	NAS1149D0316J	WASHER
10	10	MS21042L3	NUT

11.0 WEIGHT AND BALANCE

The following weight and balance changes are applicable:

Installation	Weight	LONGITUDINAL		LATERAL	
		Arm	Moment	Arm	Moment
D119-646-313 SKIDTUBE PROTECTOR, LH ON STANDARD SKIDTUBE	4.3 lb 1.95 kg	108.1 in 2.74 m	465 in-lb 5.3 kg-m	-43.4 in -1.1 m	-187 in-lb -2.2 kg-m
D119-646-314 SKIDTUBE PROTECTOR, RH ON STANDARD SKIDTUBE	4.3 lb 1.95 kg	108.1 in 2.74 m	465 in-lb 5.3 kg-m	43.4 in 1.1 m	187 in-lb 2.2 kg-m
D119-646-313 SKIDTUBE PROTECTOR, LH ON FLOAT SKIDTUBE	1.6 lb 0.72 kg	133.3 in 3.38 m	213 in-lb 2.4 kg-m	-43.4 in -1.1 in	-69 in-lb -0.8 kg-in
D119-646-314 SKIDTUBE PROTECTOR, RH ON FLOAT SKIDTUBE	1.6 lb 0.72 kg	133.3 in 3.38 m	213 in-lb 2.4 kg-m	43.4 in 1.1 in	69 in-lb 0.8 kg-in

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC. EUGENE, OR	
DRAWN	MW		
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 8 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	<small>COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.</small>	




FIGURE 1: D119-646-314 SKIDTUBE PROTECTOR KIT, RH (SHOWN)
(D119-646-313 SKIDTUBE PROTECTOR, LH (OPPOSITE))
(SHOWN INSTALLED ON D119-646-011/-012/-111/-112 SKIDTUBES)




FIGURE 2: D119-646-314 SKIDTUBE PROTECTOR KIT, RH (SHOWN)
(D119-646-313 SKIDTUBE PROTECTOR, LH (OPPOSITE))
(SHOWN INSTALLED ON D119-646-211/-212 SKIDTUBES)


APPROVED

DESIGN	RF	DART AEROSPACE USA, INC. EUGENE, OR	
DRAWN	MW		
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 9 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	


NOTES:

- 1) D5374-3 BUSHINGS ARE ONLY USED WITH:
 - D119-646-011/-012/-041/-111/-112/-141/-241 CHG 004 AND PRIOR
 - D119-646-211/-212 CHG 005 AND PRIOR
 - D119-646-013/-014/-043/-113/-114/-143/-243* CHG 005 AND PRIOR
 - D119-646-213/-214 CHG 006 AND PRIOR


D



SECTION A-A



SECTION B-B



SECTION C-C


(D5369-2 NOT SHOWN FOR CLARITY)

APPROVED

D

* D119-646-243 S/N S089679, S094961, S106182, S106198 have been modified at the factory and do not require bushings. They should be installed as CHG 006 Skidtubes.

DESIGN	RF	DART AEROSPACE USA, INC. EUGENE, OR	
DRAWN	MW		
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 10 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	



DETAIL D

FIGURE 3: USING D5376-1 DRILLING JIG

D5376-1 DRILLING JIG IS ONLY USED WITH SKIDTUBE ASSEMBLIES:

- D119-646-011/-012/-041/-111/-112/-141/-241 CHG 004 AND PRIOR
- D119-646-211/-212 CHG 005 AND PRIOR
- D119-646-013/-014/-043/-113/-114/-143/-243* CHG 005 AND PRIOR
- D119-646-213/-214 CHG 006 AND PRIOR



* D119-646-243 S/N S089679, S094961, S106182, S106198 have been modified at the factory and do not require bushings. They should be installed as CHG 006 Skidtubes.

APPROVED

DESIGN	RF
DRAWN	MW
CHECKED	ZF
MFG. APPR.	N/A
APPROVED	NO
DE APPR.	DS
DATE	18.08.24

DART AEROSPACE USA, INC.
 EUGENE, OR

DRAWING NO.

DSI 9734

TITLE

SKIDTUBE PROTECTOR KIT

REV. D



SHEET 11 OF 15

SCALE

NTS

COPYRIGHT © 2015 BY DART AEROSPACE USA, INC.

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.



DETAIL E

FIGURE 4: D5372-1 PLUG INSTALLATION

D5374-3 BUSHINGS ARE ONLY USED WITH SKIDTUBE ASSEMBLIES:

- D119-646-011/-012/-041/-111/-112/-141/-241 CHG 004 AND PRIOR
- D119-646-211/-212 CHG 005 AND PRIOR
- D119-646-013/-014/-043/-113/-114/-143/-243* CHG 005 AND PRIOR
- D119-646-213/-214 CHG 006 AND PRIOR





* D119-646-243 S/N S089679, S094961, S106182, S106198 have been modified at the factory and do not require bushings. They should be installed as CHG 006 Skid tubes.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC. EUGENE, OR	
DRAWN	MW		
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 12 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	<small>COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.</small>	





DETAIL F

FIGURE 5: D5371-1/-2 HOOK INSTALLATION

D5374-3 BUSHINGS ARE ONLY USED WITH SKIDTUBE ASSEMBLIES:

- D119-646-011/-012/-041/-111/-112/-141/-241 CHG 004 AND PRIOR
- D119-646-211/-212 CHG 005 AND PRIOR
- D119-646-013/-014/-043/-113/-114/-143/-243* CHG 005 AND PRIOR
- D119-646-213/-214 CHG 006 AND PRIOR





* D119-646-243 S/N S089679, S094961, S106182, S106198 have been modified at the factory and do not require bushings. They should be installed as CHG 006 Skidtubes.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC. EUGENE, OR	
DRAWN	MW		
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 13 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	

NOTES:

1) D5371-1/2 HOOK ASSEMBLY SHOWN, D5372-1 PLUG ASSEMBLY SIMILAR.



DETAIL G

FIGURE 6: HOOK & PLUG INSTALLATION

NAS1149D0316J and NAS1149D0332J WASHER BUILDUP IS ONLY USED WITH SKIDTUBE ASSEMBLIES:

- D119-646-011/-012/-041/-111/-112/-141/-241 CHG 005 AND SUBSEQUENT
- D119-646-211/-212 CHG 006 AND SUBSEQUENT
- D119-646-013/-014/-043/-113/-114/-143/-243* CHG 006 AND SUBSEQUENT
- D119-646-213/-214 CHG 007 AND SUBSEQUENT



* D119-646-243 S/N S089679, S094961, S106182, S106198 have been modified at the factory and do not require bushings. They should be installed as CHG 006 Skidtubes.

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC.	
DRAWN	MW	EUGENE, OR	
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 14 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC.	
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.			




FIGURE 7: D119-646-314 SKIDTUBE PROTECTOR KIT, RH (SHOWN)
 (D119-646-313 SKIDTUBE PROTECTOR, LH (OPPOSITE))
 (SHOWN INSTALLED ON D119-646-013/-014/-113/-114 SKIDTUBES)




FIGURE 8: D119-646-314 SKIDTUBE PROTECTOR KIT, RH (SHOWN)
 (D119-646-313 SKIDTUBE PROTECTOR, LH (OPPOSITE))
 (SHOWN INSTALLED ON D119-646-213/-214 SKIDTUBES)

APPROVED

DESIGN	RF	DART AEROSPACE USA, INC. EUGENE, OR	
DRAWN	MW		
CHECKED	ZF	DRAWING NO.	REV. D
MFG. APPR.	N/A	DSI 9734	SHEET 15 OF 15
APPROVED	NO	TITLE	SCALE
DE APPR.	DS	SKIDTUBE PROTECTOR KIT	NTS
DATE	18.08.24	COPYRIGHT © 2015 BY DART AEROSPACE USA, INC. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	